FRONTLINE

1. Power
2. Mute
3. TV – Opens the Guide
4. PVR – Opens the PVR
5. Select the Movies App
6. Select your Favourites
7. Search – Search
8. Left – Keyboard and Mouse - Scroll Left
9. Up – Keyboard and Mouse - Scroll Up
10. Right – Keyboard and Mouse - Scroll Right
11. Setting – Go to the Settings
12. Click L – Keyboard and Mouse – Mouse Left Click
13. Down – Keyboard and Mouse – Scroll Down
14. Click R – Keyboard and Mouse – Mouse Right Click
15. PVR - Rewind
16. PVR - Pause/Play
17. PVR - Fast Forward
18. PVR - Stop
19. Launch Home
20. Launch Addition Info
21. TV Guide – Scroll Up
22. TV Guide – Scroll Left
23. OK – Select currently highlighted item
24. TV Guide – Go back to TV. When watching TV, pressing this button brings up a submenu for:
    a. Go to Channel Selection
    b. PVR controls
25. Go back
26. Page + – TV Guide – Page Up, Quick Scrolling
27. Vol – Volume Controls
28. Ch. – Channel Controls
29. Page - – TV Guide – Page Down, Quick Scrolling
30. 0 ... 9 – Channel Inputs
31. Last – Go to last channel
32. Del – Delete

FOR FUTHER QUESTIONS PLEASE CONTACT INFO@FRONTLINE.CA

Frontline is a transmission agent of Colba.Net